

Quality is not an act,
it is a habit...

The Nightingale VERONNA™
is 66% Recyclable

Quality is not an act,
it is a habit...

The Nightingale VERONNA™
is 66% Recyclable

Quality is not an act,
it is a habit...

The Nightingale VERONNA™
is 66% Recyclable

How To Care For Your Verona™

With regular care and maintenance, your VERONNA™ will provide many years of superior performance and satisfaction. To maintain the quality of your Nightingale product, please follow the cleaning procedures outlined here.

Mechanism

Oil sparingly moving parts once a year with light machine oil.
NOTE: to prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

Fabric

Clean with mild detergent and water applied with a damp clean cloth or sponge. Rinse with water. Never use hot water and avoid scrubbing. Use gentle movements.

Plastic parts

Clean with mild detergent and water. Do not use abrasives or excessive amounts of cleaner.

Frame

Powder coat frames can be cleaned by wiping with a damp cloth and any mild detergent.

* The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.



Nightingale Office Chairs
Toll-Free Phone: 1.800.363.8954
Fax: 1.800.637.6784
Website: www.nightingalechairs.com
Email: info@nightingalechairs.com



SCAN this QR Code To Learn
More About How To Use
This VERONNA Chair.

User Guide Instructions



MANUFACTURING CONTRACT OFFICE CHAIRS SINCE 1928

VERONNA™



MODEL 7000
SHOWN



66%
RECYCLABLE

Congratulations On Purchasing Nightingale's VERONNA™


Please read and understand this user guide with instructions before operating this office chair.



A. Pneumatic Height Adjustment
To lower height, pull lever up while seated. To raise seat height, pull lever up with weight off the chair.



B. Tension Knob Turn clockwise to increase tension, turn counter-clockwise to decrease tension.



C. Lumbar Height Adjustment
To raise lumbar height support, simultaneously pull up levers on each side of back lumbar adjustment. To lower Lumbar support, simultaneously push down both sides of the Lumbar support levers.



D. Infinite Position Tilt Lock
To lock tilt in position, turn knob backwards. To unlock chair, turn knob forward and lean back to release the lock.



E. Arm Height Adjustment
To raise or lower arm height push button up and move arm to desired position. Release to lock.



F. Arm Pad Width Adjustment
To increase or decrease arm pad width adjustment, push arm pad to desired position.



G. Arm Pad Front to Back Adjustment
Push arm pad forward or pull backward to desired position for increased or decreased arm support.



H. Arm Pad Pivot Adjustment
Turn arm pads inward to desired position for increased arm support.



I. Seat Slide Adjustment
To slide seat forward, lock tilt (D) in upright position. Push button in to activate seat slide and slide the seat forward to desired position, release button to lock. To return seat to original position, push button in and remove weight from chair. Release button when seat is moved back to desired position.

How To Use and Adjust My VERONNA™



Office
Chairs

PASS IT ON!

Our customers often tell us their friends stop and ask about their VERONNA™. If this happens to you, please give your friend this card so they can learn more about our chairs.

Nightingalechairs.com
1.800.363.8954
info@nightingalechairs.com



Office
Chairs

PASS IT ON!

Our customers often tell us their friends stop and ask about their VERONNA™. If this happens to you, please give your friend this card so they can learn more about our chairs.

Nightingalechairs.com
1.800.363.8954
info@nightingalechairs.com



Office
Chairs

PASS IT ON!

Our customers often tell us their friends stop and ask about their VERONNA™. If this happens to you, please give your friend this card so they can learn more about our chairs.

Nightingalechairs.com
1.800.363.8954
info@nightingalechairs.com